







DEINONYCHUS with Sky



Defense lasers

Parts tree

Bandolier

Parts tree

Water skin

Handgun


Rifle

Ladder

AMP


1

Carefully twist all parts off the parts trees. To assemble the rocket seat, hook the top of the seat insert first. Then snap the bottom in place.





2

Carefully follow the drawing below to assemble the remaining parts.



3


Press the secret button on the back of your *Deinonychus* to make him run.



Hint: Put the dino's legs thru the harness and pull it up like a pair of pants. Then hook the harness over the edges of the seat platform.

4

The rifle and handgun clip on Sky's arm. The water skin and bandolier are worn over each shoulder. The AMP unit is worn around his neck.



If you have any comments or questions about your Tyco Dino-Riders Action Figures, please call us.

TOLL FREE
1-800-257-7728

IN NEW JERSEY
1-800-322-8011

Tyco Dino-Riders 90-Day Limited Warranty

All Tyco products are thoroughly inspected and tested before shipment and guaranteed to be free from factory defects in materials or workmanship. If you find a defective part in your set — within 90 days of the date of purchase mail the product along with proof of the date of purchase to:

TYCO SUPER-FAST SERVICE, 540 Glen Avenue, Moorestown, NJ 08057

We will repair or provide a replacement part or unit without charge. To prevent damage in transit, please pack securely. This warranty does not cover damage resulting from accident, misuse or abuse. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Tyco Industries, Inc.
Moorestown, NJ 08057

TYCO®

PRINTED IN HONG KONG

97-8-070