



PACHYRHINOSAURUS








Open the battery door on the underside of the Pachyrhinosaurus by sliding the latch forward and lifting. Install one C-size battery, being sure to put it in the right direction as shown.


Replace the battery door and slide the latch shut.

2

Fit the Weapons Platform on to the Pachyrhinosaurus. To hold it in place, stretch the Belly Band between the hooks at each side.


Fit the Gun Tips on to the Tri-Laser Cannons. Mount them on each side of the Weapons Platform. Mount the seat on the front of the Weapons Platform.





4

The AMP is worn around Atlas's neck. The Chest Shield, Psyche Blade and Infrared Night Scope clip on as shown. Mount the Double Barrel Rifle on to the Rifle Harness. This gun can be carried by Atlas on his back. It easily swings into firing position when needed.





If you have any comments or questions about your Tyco Dino-Rider playsets, please call us.

1-800-FOR-TYCO

TYCO Dino-Riders 90-Day Limited Warranty

All Tyco products are thoroughly inspected and tested before shipment and guaranteed to be free from factory defects in materials or workmanship. If you find a defective part in your set — within 90 days of the date of purchase mail the product along with the proof of the date of purchase to:

TYCO CUSTOMER SERVICE, 540 Glen Avenue, Moorestown, NJ 08057

We will repair or provide a replacement part or unit without charge. To prevent damage in transit, please pack securely. This warranty does not cover damage resulting from accident, misuse or abuse. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

©Tyco Industries, Inc., Moorestown, New Jersey 08057



Printed in Hong Kong 1989

97-8-221