




















TOROSAURUS

with *Gunnur* and *Magnus*



Accessories may or may not be attached to parts tree.

Note: One (1) "C" size battery and one (1) "AA" size battery are required.



1


Install the "C" size battery in the battery compartment on the underside of *Torosaurus*.

PLEASE NOTE

Battery life and product function can be limited by use on soft surfaces such as deep-pile carpets.


2

Press the tail ring into the rear armor shell. Hook one side of the harness strap onto the harness.



4

Stand *Torosaurus* on his feet. Lift the battery box cover off the top of the harness. Install the "AA" size battery and replace the cover.



5



Press the large and small panel gun tips onto the 7 front gun panels. Press the remaining 2 small panel gun tips onto the rear gun panel.

6

Snap the front gun panels in place.


Important. They must be installed in the following sequence. 1, 2R, 3R, 4R, 2L, 3L, 4L.

Follow the drawing carefully to orient the lift tabs for panels 3 and 4.




3


Hold harness/rear armor assembly upside down in one hand. Place *Torosaurus* upside down into harness as shown. Important! Be sure to place *Torosaurus*' tail through the tail ring first. Stretch the harness strap across *Torosaurus*' belly and hook on opposite side of harness.




Rear side is marked with an "R".




Contoured side of ring faces forward.



IMPORTANT!!




Note: On-off switch is accessible through center hole of harness strap.





8

Mount the rear gun panel and grapple cannon first. Then mount the winch and the grapple hook. Wind up the extra cable.



Front Gun Panel



Assemble the 2 halves of the winch, trapping the winch spring inside. Thread one end of the grapple cable into the hole on the grapple hook and tie a knot. Thread the other end into the hole on the winch and tie a knot.




9

Mount the pod guns and tips. Push the pod assembly into the ring on the back of the rear armor shell.

Gunnur and *Magnus* ride in each pod. Pods can be raised or lowered. They can also be rotated so that *Gunnur* and *Magnus* are completely protected by the pod armor.

**10**

Mount the left and right trippers by snapping them over the metal pins on the armor shell. Trippers are hand operated and can be set in any position — from full forward for walking to full spread trip position for stopping T-Rex.



If you have any comments or questions about your Tyco Dino-Rider playsets, please call us.

TOLL FREE
1-800-257-7728


IN NEW JERSEY
1-800-322-8011

Tyco Industries, Inc.
Moorestown, NJ 08057



11

Turn on the switch located under *Torosaurus* and he lumbers into battle.

Press the lever to open *Torosaurus*' armor and reveal the devastating light cannon. The armor will remain open. Press the lever a little farther down and the cannons will fire.

**12**

The rifles and hand guns clip on the Dino-Riders' arm. The water skins and bandoliers are worn over each shoulder. The AMP units are worn around their necks. Snap the top ends of the ladder together. It will hook over various objects to help your Dino-Riders climb.



Tyco Dino-Riders 90-Day Limited Warranty

All Tyco products are subjected to a thorough inspection and test program before shipment and are guaranteed to be free from factory defects in materials or workmanship. If you find a defective part in your set — mail the product within 90 days of the date of purchase, along with proof of the date of purchase, to:

TYCO SUPER-FAST SERVICE, 540 Glen Avenue, Moorestown, NJ 08057. We will repair or provide a replacement part or unit without charge. To prevent damage in transit, please pack securely. This warranty does not cover damage resulting from accident, misuse or abuse. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

TYCO[®]

PRINTED IN HONG KONG
97-8-078